



Specifications

Functionality	Standard	PRIME
	<i>Cloud-based network management for distributed enterprises</i>	<i>Advanced, location-based all device network management</i>
Dashboard		
Account (Aggregate) Dashboard	✓	✓
Analytics	✓	✓
+ Aggregate Data Usage	✓	✓
+ Cellular Data	✓	✓
Location Services Map (Entire Network)	✗	✓
Device		
Device Dashboard / Analytics	✓	✓
Edit Configuration	✓	✓
Net Interface Status	✓	✓
Export Device/Net Interface Config	✓	✓
Rogue AP Detection	✓	✓
Copy Config to Group	✓	✓
Clear Config	✓	✓
Troubleshooting	✓	✓
+ Ping	✓	✓
+ Traceroute	✓	✓
Reboot	✓	✓
Restore to Defaults	✓	✓
Device Logs	✓	✓
WiFi Site Survey	✓	✓
Location Services	✗	✓
+ Map Location	✗	✓
+ Geo-fence	✗	✓
Linked Router Management (LLDP)	✗	✓
Advanced Enterprise Routing	✗	✓
+ OSPF/BGP/RIP	✗	✓
+ VRRP	✗	✓
+ STP	✗	✓
+ NHRP	✗	✓
More Advanced VPN & Tunneling Protocols	✗	✓
+ OpenVPN (SSL VPN) ¹	✗	✓
+ L2TP	✗	✓
NEMO/DMNR Primary	✗	✓
NEMO/DMNR Failover	✗	✓
Console	✗	✓
+ Command Line Interface (CLI)	✗	✓
+ Out-of-Band Management	✗	✓
Historical Data	✓ 30 Days	✓ 90 Days
Modems		
Multi-carrier Software Defined Radio	✓	✓
Firmware Update	✓	✓
Groups		
Group Dashboard	✓	✓
Create/Manage Groups	✓	✓
Edit Configuration	✓	✓
Router Firmware Updates	✓	✓
Location Services	✗	✓
+ Map Location	✗	✓
Accounts and Users		
Manage Users	✓	✓
Permission Levels	✓	✓
Alerts		
Alert Management	✓	✓
Reports		
Reporting	✓	✓